

LIMITED WARRANTY, DISCLAIMER AND LIMITATION OF REMEDIES

Good Directions, Inc. warrants its spark screens (whether sold separately or as part of fire pit or fire bowl assemblies) to be free from defects in material and workmanship for one (1) year from the date of original purchase, provided that the applicable product was (i) used in accordance with Good Directions, Inc. recommended usages, and (ii) purchased directly from Good Directions, Inc. or from an Authorized Good Directions, Inc. Dealer.

Good Directions, Inc. warrants its fire domes (whether sold separately or as part of fire pit or fire bowl assemblies) to be free from defects in material and workmanship for three (3) years from the date of original purchase, provided that the applicable product was (i) used in accordance with Good Directions, Inc. recommended usages, and (ii) purchased directly from Good Directions, Inc. or from an Authorized Good Directions, Inc. Dealer.

This limited warranty covers defects in material and workmanship and Good Directions will, at its option, repair or replace a defective product or product component or refund the purchase price paid for the defective product. This limited warranty does not apply to any changes in finish color of copper or golden leaf components (which is expected to occur over time), product damage resulting from reasonable wear and tear, improper installation, service or product alteration performed by unauthorized service agents, neglect, accident, theft/vandalism, misuse, or exposure to extremes of heat, humidity, corrosive environments or other Acts of Nature.

Good Directions, Inc. will endeavor to supply original replacement parts; however, replacement parts may differ from original parts.

ALL IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO ONE (1) YEAR FROM THE DATE OF ORIGINAL PURCHASE. IN NO EVENT WILL GOOD DIRECTIONS, INC. BE RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM USE OF THIS PRODUCT, UNLESS SPECIFICALLY REQUIRED BY APPLICABLE STATE LAW.

Good Directions, Inc. makes no other warranties of any kind, either expressed or implied. No dealer, employee, agent, nor any third party, may create or assume any other liability, obligation, or responsibility on behalf of Good Directions, Inc. This Limited Warranty provides purchasers with specific legal rights and other legal rights may also apply, which vary from state to state. This Warranty is not a warranty of future performance or a statement of the useful life of any Good Directions, Inc. product, but only a warranty to repair, replace, or refund.



Fire Pit Product Manual



Contains assembly & care information for item #'s:
771 • 772 • FB-2 • FB-3 • FB-4 • FB-5 • FD-1 • FD-2 • FD-3 • FP-2



Table of Contents

Please read and understand this entire manual before attempting to assemble, operate, or install the product.

Table of Contents.....	2
Assembly Instructions for Items # 771, 772.....	3
Assembly Instructions for Items # FB-2 , FB-3, FB-4, FB-5.....	4
Assembly Instructions for Items # FP-2, FD-1, FD-2, FD-3.....	5
Important Safety Information.....	6
Care and Maintenance.....	7
Warranty.....	8



771 Fire Pit (Page 3)



FB-2 FireBowl™ (Page 4)



FP-2 Fire Pit (Page 5)

Care and Maintenance

Thank you for purchasing a Good Directions Fire Pit. With proper care and maintenance your fire pit will provide you with years of enjoyment. Your fire pit is made of metal and will react to the weather and heat.

- To extend the life of your fire pit, we recommend cleaning out the ash after each use.
- Do not clean out the fire pit until it has cooled down completely.
- When cooled and not in use, keep the fire pit covered or store in a dry location.
- Finish will not look the same after burning.
- You may clean this fire pit with mild soap and water, if desired.



CALIFORNIA PROPOSITION 65 WARNING: This product can expose you to carbon monoxide, which is a combustion byproduct known to the State of California to cause birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.



Important Safety Information

WARNING - FOR YOUR SAFETY


- For OUTDOOR use only. Do not use in a building, garage or any other enclosed area.
- Never leave a fire unattended.
- Always use a spark screen when fire is lit.
- This fire pit should not be used in or on boats or recreational vehicles.
- Do not use this fire pit directly under overhanging trees or near combustibles.
- Do not use the fire pit indoors. Carbon monoxide fume hazard.
- Do not burn flammable liquid such as gasoline, kerosene or starter fluid in fire pit.
- Keep all flammable liquids away from fire pit.
- This fire pit is designed to burn untreated wood or charcoal only.
- Do not use the fire pit as a stove.
- Do not use this fire pit on a wood deck or other combustible surfaces such as grass, leaves, mulch, etc.
- Do not touch the fire pit and spark screen while in use. It is HOT.
- The fire pit and spark screen remain very hot after use. Do not touch or move until it cools down.
- Do not wear flammable or loose clothing when operating this outdoor fire pit.
- Do not allow children or pets near the fire without supervision.
- Use a poker or heat-resistant gloves to open/close spark screen while in use or until screen has cooled off.
- Keep a fire extinguisher nearby.
- Do not overfill your fire pit.

Package Content and Assembly Instructions

Items 771, 772



Part	Description	Quantity
A	Black Iron Grate	1
B	Copper Fire Pit	1
C	Black Iron Base	1






Package Content and Assembly Instructions

Items FB-2, FB-3, FB-4, FB-5

Part	Description	Quantity
A	FireDome™ OR Spark Screen	1
B	FireDome™ Ring (included with FireDome™ only)	1
C	Handles with Nuts	2
D	Fire Bowl	1
E	Bolt	1
F	Bowl Base	1
G	FireDome™ Lifting Tool (included with FireDome™ only)	1

1. Insert Bolt (E) through center hole of the Bowl Base (F) and fasten to welded nut on cross bar.
2. Mount Handles (C) to Fire Bowl (D) as shown.
3. Place FireDome™ Ring (B) on top of bowl (slanted tabs up). FireDome™ Ring only necessary when using a FireDome™
4. Place FireDome™ or Spark Screen (A) on top of Fire Bowl



Package Content and Assembly Instructions

Items FP-2, FD-1, FD-2, FD-3

Part	Description	Quantity
A	Fire Pit Bowl	1
B	Fire Pit Ring	1
C	Fire Pit Leg Assembly	2
D	Nuts	1
E	Bolt	1
F	FireDome™ OR Spark Screen	1
G	FireDome™ Lifting Tool (included with FireDome™ only)	1

1. Place Fire Pit Ring (B) on flat surface with threaded studs facing up
2. Put Leg Assembly (C) together as shown. DO NOT TIGHTEN CENTER BOLT – leave loose.
3. Align and insert leg holes onto threaded studs. Add nuts (D), leave loose until they are in place then tighten.
4. Tighten center Bolt (E) and nut using a screwdriver and wrench as pictured.
5. Turn assembly over, drop fire pit in ring.
6. Place Spark Screen or FireDome™ (F) on top.

