



Thank you for purchasing a Good Directions Fire Pit. With proper care and maintenance your fire pit will provide you with years of enjoyment. Your fire pit is made of metal and will react to the weather and heat.

#### Care and Maintenance

- To extend the life of your fire pit, we recommend cleaning out the ash after each use. Do not clean out the fire pit until it has cooled down completely.
- When cooled and not in use, keep the fire pit covered or store in a dry location.
- Finish will not look the same after burning.
- You may clean this fire pit with mild soap and water, if desired.

#### One Year Limited Warranty

We warrant to the original consumer/purchaser that all components of this product are free of manufacturing defects for one (1) year from date of purchase.

If you have questions about your fire pit please contact us at [contact@gooddirections.com](mailto:contact@gooddirections.com). To view our full line of products, visit our website at [www.gooddirections.com](http://www.gooddirections.com)

Retain this manual for future use.



# Copper Fire Pit Assembly Instructions




# Package Contents & Assembly Instructions

For Medium and Large Copper Fire Pits (771, 772)



Part	Description	Quantity
A	Black Iron Grate	1
B	Copper Fire Pit	1
C	Black Iron Base	1



1. Place the Black Iron Base on a flat surface.
2. Place the Copper Fire Pit into the Black Iron Base.
3. Place the Black Iron Grate into the Copper Fire Pit.

## SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate, or install the product.

### WARNING - FOR YOUR SAFETY

- For OUTDOOR use only, do not use in a building, garage, or any other enclosed area.
- Never leave a fire unattended.
- Always use a spark screen when fire is lit.
- This fire pit should not be used in or on boats or recreational vehicles.
- Do not use this fire pit directly under overhanging trees or near combustibles.
- Do not use the fire pit indoors. Carbon monoxide fume hazard.
- Do not burn flammable liquid such as gasoline, kerosene or starter fluid in fire pit.
- Keep all flammable liquids away from fire pit.
- This fire pit is designed to burn untreated wood or charcoal only.
- Do not use the fire pit as a stove.
- Do not use this fire pit on a wood deck or other combustible surfaces such as grass, leaves, mulch, etc.
- Do not touch the fire pit and spark screen while in use. It is HOT.
- The fire pit and spark screen remain very hot after use. Do not touch or move until it cools down.
- Do not wear flammable or loose clothing when operating this outdoor fire pit.
- Not for use by children.
- Do not allow children or pets near the fire without supervision.
- Use a poker or heat-resistant gloves to open/close spark screen while in use or until screen has cooled off.
- Keep a fire extinguisher nearby.
- Do not overfill your fire pit.



**WARNING:** Combustion byproducts produced when using this product include carbon monoxide and other chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

Consumers should check state and local codes and regulations regarding the use of this product.